



2021 Rivian R1T

Towing



Make all Connections to Tow Truck before "Free Rolling" Vehicle



Connection Points for Loading to Rollback Tow Truck are at the Front Control Arms with a Nylon Wrap Around Style Bridle (Shown)



Nylon Bridle will lay flat on lower Front Bumper during loading

To Free Roll Vehicle:

- Turn Vehicle On, Place Foot on Brake
- From the center display, select:
Gear icon > Vehicle > Service
- Then toggle on '**Park Brake Release**'

This will disengage the rear park brake and the vehicle will roll freely in this mode for 15 minutes.

After loading the vehicle, toggle off the Park Brake Release in the center display by following the same steps above.



Attention

Winch Line Hook may contact front bumper during loading due to steep Rollback loading angle or short leg bridle assembly.



8 Point Retention ONLY