

Collapsible Spare Tire

Volkswagen/Audi/Porsche

Collapsible spare tires are found in several different VWGoA vehicles including:

- All Audi Q5 models
- Audi Q7 – MY 2016 and later
- Porsche Macan
- Porsche Cayenne



Volkswagen Touareg

Supplied Air Compressor



Audi Q5



Supplied Air Compressor



12-volt power source in the cargo area



Connect the air line to the valve stem, then plug in the compressor to the power source.



Fill the tire to the recommended tire pressure specifications.

Notes:

- The recommended tire pressure specification can be found on the tire pressure tag in the driver door jamb.
- The total fill time with supplied compressor should be around 10 minutes.
- The vehicle's ignition will need to be placed in the "ON" position to energize the 12-volt power point in the cargo area.