




2022 Ford F-150 Lightning EV

Towing & Neutral Mode

Prior to activating Neutral Mode, make all connections to tow vehicle to prevent roll away.



Make connections to the disabled F-150 Lightning at the transport slots in the bottom of the frame behind the sway bar mounts

There are **three** pathways to get the F-150 lightning into neutral.




Check for green READY light in dash cluster




In SYNC screen, select
Settings > Vehicle > press and hold
Emergency Tow



Press brake, shift to Neutral (N),
press temporary neutral button
twice, turn off vehicle



Press brake and accelerator pedals
all the way down to unlock shifter



30min Neutral Mode
enabled
Not a Tow Mode

OK



To turn off **Neutral Mode** place vehicle back **Park**
Select Park and set Park Brake during transport